





SAP no. 855368




2 sec



- 1 Status bar/level
- 2 Reference
- 3 Main line (result)
- 4 Active function
- 5 Selection keys linked to the symbol above
- 6 ON/DIST
- 7 Clear/OFF
- 8 Function screen
- 9 Zoom
- 10 Add
- 11 Subtract
- 12 Reference
- 13 Navigation

Quick Start

Leica DISTO™ X4






ON



OFF

2 sec




Unlock keypad



Within 2 sec.

- when it has to be right

FUNC Functions FUNC



	Single distance measurement
	Area
	Volume
	Room angle
	Smart Horizontal Mode
	Level
	Pythagoras
	Stake out
	Timer
	Height tracking
	Memory
	Point to point measurement*
	Point to point measurement levelled*
	Smart area measurement*

*Activated when connected to DST 360

FUNC Settings




	Tilt units
	Distance units
	Turning screen
	Beep
	Bluetooth®
	Bluetooth® settings
	Illumination
	Favourites
	Keypad lock
	Tilt calibration
	Information / Serial number
	Offset
	Calibration of DST 360*
	Reset

FUNC or



Zoom



Details

